



INSTALLATION GUIDE

3D TEXTURED DECORATIVE WALL

Preparing for the Installation:

By following the instructions below, you will maximize the beauty of your 3D Textured Decorative Wall Panels:

1) What you will need:

- a. Tubes of Construction Grade Adhesive (like Liquid Nails) (Do NOT use Wood Glue)
- b. Caulk Gun
- c. Optional: Pin Nailer and 1 ¼" Finish Pin Nails, or Brace Supports (i.e. 2x4s, etc)

(Note: there are some construction adhesives that will not require you to fasten the board to the wall with pins or screws while the adhesive sets and dries. See adhesive instructions for specific directions)

2) Installation:

- a. Find the studs on the wall and mark them where you will be attaching the panels.
- b. Apply the construction adhesive to the back of the panel as recommended by the adhesive manufacturer.
- c. Set the panel to the wall in the desired location. Be sure to press the board tight to the wall so the adhesive will spread out evenly along the board and wall. You may need to slide the board back and forth slightly to smooth the adhesive.
- d. Secure panel to the wall either with braces or mechanically to keep the board from moving as the adhesive sets. To do this you need to fire a 1 ¼ inch pin (with pin nailer) into the stud through the panel near each corner of the panel and 2-4 throughout the mid-section. The finish pins are very thin and will not be noticeable, however feel free to cover them with either touch up **paint or putty**. **Without the adhesive the pins will not be sufficient to hold the panel to the wall, they are only intended to keep the panel from moving while the adhesive is curing.**