



ASSEMBLY INSTRUCTION

1. INSERT BOW ARM(E) INTO BOW ARM UPRIGHT(D). TIGHTEN SCREWS.
2. OPEN THE BASE FRAME UNTIL IT LOCKS. INSERT STRAIGHT ARM(B) INTO OPEN END OF BASE FRAME (A) UNTIL BUTTON POPS OUT OF FIRST ADJUSTABLE HOLE. PUSH IN BUTTON AND REPEAT TO ADJUST HEIGHT.
3. REPEAT STEP 2 FOR SLANT ARM(C) AND BOW ARM(D).
4. INSERT FINIALS(F) INTO TOP OF THE THREE ARMS.

PARTS LIST

1	BASE FRAME (A)
1	STRAIGHT ARM (B)
1	SLANT ARM (C)
1	BOW ARM UPRIGHT (D)
1	BOW ARM (E)
3	FINIALS (F)
3	LEVELERS (G)