



ASSEMBLY INSTRUCTION

1. TO FIX BOTTOM GLASS FRAME ON THE UPRIGHT, SCREW 1ST GLASS FRAME(C) ONTO UPRIGHT 1 (A) AND UPRIGHT 2 (B), (AS PICTURE INDICATED IN LEFT SIDE).
2. REPEAT STEP 2 TO INSTALL 2ND GLASS FRAME.
3. REPEAT STEP 3 TO INSTALL 3RD GLASS FRAME.
4. REPEAT STEP 4 TO INSTALL 4TH GLASS FRAME.
5. TIGHTEN ALL SCREWS, THEN, PUT TEMPERED GLASS ON EACH FRAME.

PARTS LIST

2 UPRIGHT 1 (A)
2 UPRIGHT 2 (B)
4 GLASS FRAME (C)
16 SCREWS (D)
4 TEMPERED GLASS (E)
16 FELT PAD (F)