



ASSEMBLY INSTRUCTION

1. INSERT LEVELERS(A) INTO BOTTOM HOLES OF UPRIGHTS(B).
2. ATTACH BOTTOM RAIL(C) TO UPRIGHT(B) AND LOOSELY TIGHTEN BOLTS INTO EACH END OF UPRIGHT.
3. ATTACH TOP RAIL(D) TO UPRIGHT(B) AND TIGHTEN ALL BOLTS WITH WRENCH.
4. INSERT SHELF BRACKET(E) INTO SLOTS ON SIDES OF UPRIGHT(B) AND TIGHTEN. SHELF BRACKETS CAN BE SET TO DESIRED LOCATIONS BUT MUST BE LEVEL FOR SHELF.
5. LAY SHELF SUPPORT ON THE FRONT OF THE SHELF BRACKETS. GLASS CAN NOW BE INSTALLED.

PARTS LIST

4	LEVELER (A)
2	UPRIGHT (B)
1	BOTTOM RAIL (C)
1	TOP RAIL (D)
12	SHELF BRACKET (E)
6	SHELF SUPPORT (F)