



ASSEMBLY INSTRUCTION

1. SCREW UPRIGHT (A) AND BASKET (B) TOGETHER.
2. INSTALL METAL BRACKET (C) AND LEG (D) ONTO BOTTOM BASKET WITH AVAILABLE SCREWS.

PARTS LIST

3 UPRIGHT (A)
3 BASKET (B)
3 METAL BRACKET (C)
3 LEG (D)