



**ASSEMBLY**

**NO TOOLS REQUIRED**

1. Attach base legs (A) to uprights
2. Attach bottom face (B) to base legs
3. Attach (C) peg backs to uprights (install 7" peg back first then 12")
4. Install bottom shelf (D)
5. Install (E) wall bracket (optional)

NOTE: Add-on units require the same steps - less the upright/base legs for one side.