



RST-23 ASSEMBLY INSTRUCTIONS

PART LIST:
2 Arms
1 Upright pole
1 Steel plate
1 Base cover
1 Base weight
2 Bolts

