



ASSEMBLY INSTRUCTION

1. TIGHTEN BASE (A) AND BASE (B) TOGETHER WITH $\frac{1}{4}$ " HEX NUT (H).
2. INSERT BOTTOM UPRIGHT (C) INTO ALREADY ASSEMBLED BASE (A&B).
3. SCREW TOP UPRIGHT (D) ONTO BOTTOM UPRIGHT (C).
4. ATTACH HANGING ARMS (E) TO SPIRAL BAR (F) WITH SCREW (J).
5. SLIDE HANGING ARMS OVER UPRIGHT (D) TO DESIRED HEIGHT AND TIGHTEN SET SCREWS TO SECURE.
6. INSERT FINIAL (G) INTO TOP OF UPRIGHT (D).

| PARTS LIST | |
|------------|---|
| 1 | BASE 1 (A) |
| 2 | BASE 2 (B) |
| 1 | BOTTOM UPRIGHT (C) |
| 1 | TOP UPRIGHT (D) |
| 2 | HANGING ARM (E) |
| 1 | SPIRAL BAR (F) |
| 1 | FINIAL (G) |
| 6 | $\frac{1}{4}$ "-20 HEX NUT (H) |
| 1 | $\frac{3}{8}$ "-16x1" SCREW (I) |
| 2 | $\frac{1}{4}$ "-20x $\frac{1}{2}$ " SCREW (J) |
| 2 | M6X6.5 SET SCREW (K) |